

REMOTE INSTRUCTIONS

Auto-Program the Silver TCC Remote to your TV

(for turning the TV on and off and controlling volume)

1. Turn the TV on
2. Press the "**TV**" button on the silver remote
3. Press and hold the "**Setup**" button until it blinks twice
4. Enter **9 9 1** on the number pad; the TV key will blink twice.
5. Press 1 (the code for "TV")
6. Aim the remote at the TV and press the red **POWER** button once
7. Press and release the "CH+" (channel up) key continuously, then stop when the TV turns off.

The remote is basically trying every known code, one at a time, until it finds the right code for your TV.