



## REMOTE INSTRUCTIONS

---

### Auto-Program the Silver TCC Remote to your TV (for turning the TV on and off and controlling volume)

1. Turn the TV on
2. Press the "TV" button on the silver remote
3. Press and hold the "**Setup**" button until it blinks twice
4. Enter **9 9 1** on the number pad; the TV key will blink twice.
5. Press 1 (the code for "TV")
6. Aim the remote at the TV and press the red **POWER** button once
7. Press and release the "CH+" (channel up) key continuously, then stop when the TV turns off.

The remote is basically trying every known code, one at a time, until it finds the right code for your TV.

